




Programming of remote control, Proxima



1. Pilot
2. Remote Control



A. Press and hold one of the four buttons on the controller that shall interact with the pilot. Hold until a sound signal is heard.



B. Within 10 seconds the button on the pilot must be pressed. Hold until a sound signal is heard.
Now the remote control is ready to be used.